

## DIN AMMETER & VOLTMETERS

Size: All 2 DIN Module



RCO-1218D



RCO-1222D

### DIN AC Ammeters

Type	Code	Description
5A	<b>SQD-5A</b>	Meter without Scale Plate
1A	<b>SQD-1A</b>	Meter without Scale Plate

### Scale Plates

SQDSP-5/\*, 10/\*, 15/\*, 20/\*, 25/\*, 30/\*, 40/\*, 60/\*, 80/\*, 100/\*, 150/\*, 200/\*, 250/\*, 300/\*, 400/\*, 500/\*

\*Replace with '5A' for 5A CT Ratio or '1A' for 1A CT Ratio

DIN AC Voltmeters		DIN DC Voltmeters	
Type	Code	Type	Code
150V	<b>SQD-150VAC</b>	15VDC	<b>SQD-15VDC</b>
300V	<b>SQD-300VAC</b>	30VDC	<b>SQD-30VDC</b>
500V	<b>SQD-500VAC</b>	50VDC	<b>SQD-50VDC</b>
		150VDC	<b>SQD-150VDC</b>

DIN AC Ammeters Direct		DIN DC Ammeters Direct	
Type	Code	Type	Code
1A	<b>SQD-1AAC</b>	5A	<b>SQD-5ADC</b>
5A	<b>SQD-5AAC</b>	10A	<b>SQD-10ADC</b>
10A	<b>SQD-10AAC</b>	15A	<b>SQD-15ADC</b>
15A	<b>SQD-15AAC</b>	20A	<b>SQD-20ADC</b>
20A	<b>SQD-20AAC</b>	25A	<b>SQD-25ADC</b>
25A	<b>SQD-25AAC</b>	30A	<b>SQD-30ADC</b>
30A	<b>SQD-30AAC</b>	4-20mA (0 - 100% Scale)	<b>SQD-20MA/100</b>
		4-20mA (0 - 10% Scale)	<b>SQD-20MA/10</b>

### Frequency Meter

Code	Range	Volts
<b>SQD-45/65HZ</b>	45-65Hz	230V

### DIN Mount Ammeters & Voltmeter Selector Switches

Code	Description
<b>RCO-1218D</b>	Voltmeter selector switch 7 position 3 Phase + N
<b>RCO-1222D</b>	Ammeter selector switch for 3CT's: Off, L1, L2, L3



## DIGITAL DIN METERS



	AC Ammeter Direct	AC Voltmeter	Frequency
<b>Code</b>	<b>DM-999AAC</b>	<b>DM-600VAC</b>	<b>DM-HZ</b>
Range	C/T Ratio: 15/5, 25/5, 40/5, 60/5, 99.9/5, 150/5, 250/5, 400/5, 600/5 & 999/5A • Selectable by DIP switches	0 - 600VAC	1 - 199Hz Input Voltage: 40 - 600VAC
Accuracy	0.5%		
Supply	110/230VAC		
	DC Ammeter	DC Voltmeter	
<b>Code</b>	<b>DM-999ADC</b>	<b>DM-100VDC</b>	<b>DM-300VDC</b>
Range	15A, 25A, 40A, 60A, 99.9A, 150A, 250A, 400A, 600A, 999A/60mV • Selectable by DIP switches	0 - 100VDC	0 - 300VDC
Supply	230VAC		