


CRANE CONTROLS

Accessories		LAP	
Contact Blocks 6A AC11 @ 250V			
Single depression	1 N/O	DMK-10	
Single depression	1 N/O + 1 N/C	DMK-11	
Single depression	2 N/O	DMK-20	
Double depression	2 N/O	DMK-20PR	
	2-Way Bridge	DLACC2SQ	
	4-Way Bridge	DLACC4	
Operators			
E-Stop, twist to release		DLAE-M	
Lamp holder		DLAP-L	
Key-switch on/off		DLAK-S	
Blanking plug		DLAS-39	
Mechanical Interlock		DPK-64	
Buttons - Can be installed in any 90° Position	Red – Stop	DLAS-34	
	Green – Start	DLAS-30	
	Yellow – Alarm	DLAS-32	
	Green – Alarm	DLAS-31	
	Black	DLAS-16	
	Black	DLAS-07	
	Black	DLAS-08	
	Black	DLAS-02	
	Black	DLAS-12	
	Black	DLAS-06	
	Black	DLAS-22	
	Black	DLAS-26	
		Rubber Gasket	DLAGUA2




Single Row Pendant Stations LAP IP65		
No. Ways	Single Row	Double Dep
2	LAP-2	–
3	LAP-3	–
4	LAP-4	–
4	LAP-4D	4
6	LAP-6	–
8	LAP-8	2
8	LAP-8D	6
10	LAP-10	4
12	LAP-12	4



Accessories		PKP
Contact Blocks 6A AC11 @ 250V		
Single depression	1 N/O	DMK-10
Single depression	1 N/O + 1 N/C	DMK-11
Single depression	2 N/O	DMK-20
Double depression	2 N/O	DMK-20PR
Operators		
E-Stop, twist to release		DPK-60
Lamp holder		DPK-61
Key-switch on/off		DPK-62
Blanking plug		DPK-63
Mechanical Interlock		DPK-64
Buttons - Can be fitted in any 90° Position		
Black	DPK-72	Red – Stop
Black	DPK-75	Green – Start
Black	DPK-76	Yellow – Alarm
Black	DPK-77	Green – Alarm
Black	DPK-44	Black
Black	DPK-56	Black
		DPK-74
		DPK-73
		DPK-68
		DPK-69
		DPK-70
		DPK-71



Double Row Pendant Stations PKP IP65		
No. Ways	Single Row	Double Dep
4	PKP-4	–
6	PKP-6	–
8	PKP-8	–
10	PKP-10	2
12	PKP-12	4
14	PKP-14	6



CRANE & VEHICLE CONTROLS

Joystick Controllers

Code	Description
MW2-33	4 direction, 3 position open joystick (4 way, 3 step)
MW2-44	4 direction, 4 position open joystick (4 way, 4 step)
MW33-33*	4 direction, 3 position mobile control station (4 way, 3 step)
MW44-44*	4 direction, 4 position mobile control station (4 way, 4 step)

* Comprising two joysticks in box, 3 pushbuttons and shoulder belt

Accessories for MW2

Code	Description	Code	Description
MW-70	Knob and shaft	MW-72	Contact block 6A
MW-71	Rubber boot for shaft	MW-80	No. 1 CAM
MW-73	Legend - Hoist	MW-75	Legend - Cross Travel
MW-74	Legend - Long Travel	MW-76	Legend - Rotation

